

Overview X35 steering Assamble wheel

Guidance assamble front
A-frame and steering wheel

- 1 Mount steering wheel on conical Ø25mm shaft. Be carefull to fit the 5mm key in wheel hub
2. tighten the wheel with the special nut shaft.
- 3 Hit the M8 screw inbush 4mm from the bottom of the A-frame through a 10mm hole, and keep the Allen key inside the screw until the A-frame is mounted and the screw is tighten
4. mount the A-frame on the nut-shaft till the distance is similar between the wheel hub
5. tighten the screw with the 4mm Allenkey from the bottom of the hub in the front A-frame
6. mount the front A-frame in the bottom of the cockpit with 2pcs M12 bolts from aft part of the cabin.

