



It is allowed to remove the berths madras's and the saloon table excluding legs.

The anchor and anchor warp as specified by the class rules is to be stowed in the saloon area. Positions shown are optional.

X-Yachts
WORLD CLASS SINCE 1979

Fjordagervej 21 - Box 104 - DK-6100 Haderslev - Denmark
Tel.Int.+45 74 52 10 22 - Fax.Int.+45 74 53 03 97
e-mail: info@x-yachts.com - WWW.x-yachts.com

Yacht

X-35

Description

Position of anchor and anchor warp

Drawing Number

H9 Rev. C

Scale

1:50

Date Issued

2006.01.06